ISOTRA Basic Solar Motor - Screen Roller Shutters

Step 1	**Turning on the motor** Hold for 1 s, the motor will beep briefly and jerk	**Turning off the motor** Hold for 7 s, the motor will beep long and jerk
Step 2	**Pairing the remote control** Hold for 1 s, the motor will jerk briefly	Select the channel and confirm with the up arrow (within 10 s), the motor will confirm with a jerk
Step 3	**Changing the direction of rotation** Hold the STOP button on the remote control until the motor jerks	Confirm with the down arrow, the motor will confirm with a jerk
Step 4	**Setting the upper end position** Briefly press the Learn button on the remote control, the motor will jerk	Move to the desired upper position and confirm the Learn button, the motor will jerk
Step 5	**Setting the lower end position** Briefly press the Learn button on the remote control, the motor will jerk	Move to the desired lower position and confirm the Learn, the motor jerks
	Deleting end positions Move to the end position you want to delete and hold the Learn button for 7 seconds	The motor jerks for 1 second and then for 6 seconds, the end position has been deleted
	Copying the saved channel Select the desired channel and hold the STOP button for 5 seconds until the motor jerks	Select a new channel and confirm with the up button, the motor confirms with a jerk
	Changing from step mode to continuous operation (and vice versa) Hold the STOP button for 5 seconds until the motor jerks	Confirm the STOP button, the motor confirms with a jerk
	Changing the obstacle sensitivity - 8 levels in total Hold the up and down buttons simultaneously until the motor jerks	Together, the STOP button + the up button gradually increases the sensitivity and the STOP button + the down button decreases the sensitivity
	Delete one set channel Hold STOP button for 5 seconds until the motor jerks	Press Learn button for 1 second on the given channel, the motor will confirm with a jerk
	Delete all remote controls Hold STOP button for 5 seconds until the motor jerks	Press and hold Learn button on the remote control for 7 seconds until the motor jerks for the second time

Validity of instructions: 14. 1. 2026